

CHAPTER - V

MODELING PRESETS.

This Chapter covers:

- Properties
- Material Constant
- Geometric Constant
- Specification
- Loads & Load Types

Not For Release

In the Previous Chapter, We have discussed How to Create structure by sample Structures. For Further stages We have to add Presets to the structure, to analysis the Structure.

Various Preset for the analysis are as follows;

- Properties
- Material Constant
- Geometric Constants,
- Specifications',
- Loads.

In this chapter, we have to learn about the Presets & How to assign the Presets to the structure that list above.

So when you complete this chapter, you will be finishing all the requirements to analysis any type of Structure.

- **Prismatic property**
- **Steel property**
- **Thickness property**
- **Checking property**
- **Referencing & Reference table**
- **Deleting property**
- **Changing Units**

Property Types

As we mentioned in chapter 1, STAAD Pro needs the cross – section to calculate I (Moment of inertia), hence calculate K (Stiffness factor), and without K, Staad pro cannot complete the system of matrices mentioned before and accordingly it cannot produce the needed results.

Following are properties (Cross-Section) used to assign to Beams, Columns, and Plates.

For Beams & Columns:

- 1. Prismatic, for Concrete sections,**
- 2. Built-In steel section table,**
- 3. User created steel tables, for steel sections.**

For Plates, the only available method is Thickness.

1. PRISMATIC Property Specification:

To assign a prismatic or concrete property to a member follow this procedure:

- * Go to the menu, **Commands ->Member Property ->Prismatic** or
- * Go to **Page Control General ->Property &**





Click Define...button on the properties screen on right side.

There are 4 different cross sections, to define a concrete member.

Circle:- Provide YD for Circular.

Rectangle:-Give the Value of YD-depth & ZD-Width.

T-Beam: Specify YD, ZD, and YB & ZB. Similarly for Trapezoidal section, YD, ZD and ZB must be provided.



For the above four cross- Section, STAAD

Pro will take the values supplied by the user and calculate all the needed information, which they are:

Ax- Cross Sectional Area.

Ay-Effective Shear Area for shear forces parallel to local y axis.

Az-Effective Shear Area for shear forces parallel to local z axis.

Ix- Moment of Inertia about X-axis.

Iy- Moment of Inertia about Y-axis.

Iz-Moment of Inertia about Z-axis.

General:


As an alternate method, you can give STAAD Pro all the data needed (Ax, Ix, Iy and Iz) with or without the cross section of the Beam, by selecting General.

You will get the following screen:

Note:

In all of the above five dialogue boxes you will find a check box called **Material**, and pop-up list with selection of **Concrete**.

- Accepting this check box means you are accepting the default data available at **STAAD Pro** (to view the default material data, form **General page, Property sub-page**, click on Material button, you will get the following dialogue box)




Name	E kip/in ²	Poisson's Ratio	Density kip/in ³	Alpha @°F
STEEL	29000.000	300E-3	283E-6	6.5E-6
STAINLESSSTEEL	28000.000	300E-3	289E-6	9.9E-6
ALUMINUM	10000.000	330E-3	98E-6	12.8E-6
CONCRETE	3150.000	170E-3	86.8E-6	5.5E-6

- When you click this checkbox off you have to input the specific material constants later on.

How to assign Properties to a Section?

After selecting a section, Click Add button in Property window. You can select some more sections or click Close button. You can see the selected in Properties window as below.



Select the section and choose any one of the **Assignment Method**:

Assign To Selected Beams –if you have already chosen the members.

Assign To View :- assign the section to all members.


Use Cursor to Assign: – select the required members using the cursor

Assign To Edit List: – type required members nos. in the box.

Click **Assign**, so that selected property will be assigned.

VIEWING CROSS-SECTION:

To view cross section, right-click anywhere in STAAD window. Select **Structure Diagrams**. From the dialogue box, under **3D Section**, select **Section Outline**.



The structure will be shown as shown above. If you select **Full Section**, you will get the following result:

Render:

From **View** toolbar, select **3D Rendered View**, or from

means select **View/3D Rendering**. In all cases this is what you will get:



2. Built-In Steel Table


- From Menu, **Commands->Member Property->Steel Table->** (steel table of a respective country).or
- Go to **General Pages Control**
- Make sure you are in the **Property** sub-page
- From the properties box at the screen, click **Section Database...**

A small dialogue box will appear. Choose the suitable country table. Depending on what table you select a dialogue box with all of the cross-section will appear (we will take the Indian Steel Table as an example):

Select the desired section, and then specify the proper specification for that section.

There are mainly five different section categories:





- I-Shape
- S Shape
- W-Shape
- Angle
- T-Angle
- Channel
- Tube
- Pipe

ST means Single section as mentioned in the table.

T means T-section cut from I-section.

CM means Composite Section-Steel and Concrete. Specify:

- **CT**, the Concrete Thickness
- **CW**, the Concrete Width
- **FC**, the Concrete Grade

TC, Top Cover Plate. Specify:

- **WB**, the Width of Cover Plate
- **TH**, the Thickness of Cover Plate

BC, means Button Cover Plate. Specify the same data of TC.

TB, means top and Bottom Cover Plate. Specify the same date of TC.

Angle:

ST means standard section as mentioned in the table.

RA, means an Angle with Reverse Y-Z:

LD, means Double Angle, Long Leg Back-to-Back. Specify:

- **SP**, the space between the two Angles.

SD, Double Angle, Short Leg Back-to-Back. Specify SP also.

Channel:

ST means standard section as mentioned in the table.

D, means Double Channel Back-to-Back. Specify SP.

Tube:

Select one of the pre-defined Tubes in the table Or define your own.

- **TH**, means the Thickness of the tube
- **WT**, means the Width of the tube
- **DT**, means the Depth of the tube

Pipe:

Either select one of the pre-defined Pipes in the table or define your own.


- **OD**, means the Outside Diameter of the Pipe.
- **ID**, means the Inside Diameter of the pipe.

Note: User defined table and others are dealt in advanced chapters.

3. Thickness

- Go to **General Page Control**.
- Make sure you are in the **Property** sub-page
- Form the right of the screen, click **Thickness**

The following dialogue box will appear:




If you fill Node 1, automatically Node 2, 3, and 4 will be filled with the same value.

If you want to give different Thickness for different Nodes, go to each Node, and input the desired value, this will not affect any of the other Nodes.

General Nodes about Property Assigning:

For the three types of Properties mentioned in this chapter, there are different functions to check the other values as mentioned below:


1. After you assign Property for a **Beam**, **double-clicking** it will show you a dialogue box, select Property tab, and the following will appear:



You will see that STAAD Pro already calculated for you:

- Ax ,Ay ,and Az
- Ix , Iy ,and Iz

2. Double-Click on the plate:





Referencing

After you made your assignment, and in the data area, you will see the following:

- Each Property assigned will be given a **Ref number**, starting from 1, and it shows if you select the Material checkbox or not.

In STAAD Pro window you will see the name of the section mentioned beside each Beam, or Plate:

Clicking on the Ref will automatically select the Beams, or Plates.



This is very useful especially if you want to check your work : that is all the desired Beams


are assigned the right cross-section. If you don't want the selecting to take place, click off the check box below Reference table:

Deleting the property for a section:

If you want to delete an assignment, follow one of the methods:

- Select the **Ref number** you want to delete, and click **Delete** button in properties window.
- Select the **Ref number** and press and **Delete** at the keyboard.

In both ways, the following dialogue box will appear:



Click OK, to confirm the deletion, or **cancel** to ignore.


Reference Label

To change how the Reference Label is displayed on the screen, right-click anywhere in the STAAD Pro window, and selects Labels. From that, under Properties section you choose one of the following:

References (j), (Beside each Beam you will see r1 r2 etc.)

Sections (x), (Will Show the Cross Section beside each Beam)


None, (Noting Will seen beside the members)




Changing Input Units

When starting your problem, you have assigned one Length & force unit initially. As an alternate method you can also, change your input units, and input the dimension using the new Units.

Assuming your current length units is in **m (meters)**, and force units are in **KN (Kilo Newton)**.



To change the units do the following:

-  -From the **Structure** toolbar, select **Input Units**, or form menus select **Tools/Set Current Input Unit**. The dialogue box will appear as shown above
- Click **mms. & Newton**.


Constants

There are two types of Constants in STAAD Pro,

- **Material Constants,**
- **Geometric Constants.**

Material Constants

Materials allow the user to provide material constants such as Density, Elasticity, Poisson's Ratio, and Coefficient of Thermal Expansion etc.



The material constants are:

- **modulus of elasticity (E);**
- **weight density (DEN);**
- **Poisson's ratio (POISS);**
- **co-efficient of thermal expansion (ALPHA),**
- **Composite Damping Ratio, and beta angle (BETA) or**
- **Coordinates for any reference (REF) point.**

E value for members must be provided or the analysis will not be performed. Weight density (DEN) is used only when self weight of the structure is to be taken into account. Poisson's ratio (POISS) is used to calculate the shear modulus (commonly known as G) by the formula,

$$G = 0.5 \times E / (1 + \text{POISS})$$

If Poisson's ratio is not provided, STAAD will assume a value for this quantity based on the value of E. Coefficient of thermal expansion (ALPHA) is used to calculate the expansion of the members if temperature loads are applied. The temperature unit for temperature load and ALPHA has to be the same.

Composite damping ratio is used to compute the damping ratio for each mode in a dynamic solution. This is only useful if there are several materials with different damping ratios.

Note: Poisson's Ratio must always be defined after the Modulus of Elasticity for a given member/element.

How to assign Material constant to member?

There are three ways to assign Material Constants to Beams or Plates:


1. Using Menus,
2. Using Page Control,
3. Using Double Click,

Using Menus

Select desired Beams or plates in the Structure:

From the select **Commands/Materials**, and then select one of the following choices:

- **Material Table**
- **Density**
- **Elasticity,**
- **Poisson's Ratio,**
- **Alpha**
- **Damping Ratio,**
- **G(Shear Modulus)**



Regardless of the constant you want to input, you will get almost the same dialogue box:

Note:-

- If you have select Beams Or Plates, before the Command, then under Assign, select To Selection.
- You Can assign to all Beams, and Plates, by Selecting To View.
- You can Use F2 key to Convert Units.



Using Page Control

From General Page Control, Select General/Material sub-page.

At the right side of the Screen, Click Isotropic tab in the Material Box.

Click Create button, to Create a new Material constants, you will get following dialogue box:

Type the name of this material; input the data



you want, and click **OK**, a new Material will be added.

While the new material is selected, select desired Beams, or Plates, and click **Assign**.

Using Double Click

Double-Click on the desired Beam or Plate, a dialogue box will appear.

- Select Property tab.
- Under Material Property, there will be a pop-up list.
- Select the desired **Material**.
- Click **Assign Material**.



The image shows a 'Material Properties' dialog box with a table of material properties and a dropdown menu for material selection.

Material Properties			
Elasticity(kip/in ²)	29000	Density(kip/in ³)	0.000283
Poisson	0.3	Alpha	6.5e-006

Material Selection: STEEL (dropdown menu)

Assign Material (button)

Note:-

If you have already created an isotropic material, you will find it in the list.

Assign Methods

There are four methods to assign Material.

- Assign to Selected Beam
- Assign to View.
- Use Curser to Assign.
- Assign to Edit List.

Assign to Selected Beam

Select Nodes, Beams or Plates to assign loads, **Assign to Select Beams** enables, and Click the same, Click **Yes**.

Assign to View

In this Method, all the elements get assigned the selected material, Click **Yes**.

User Curser to Assign

In this method, user has to pick that want to assign the selected Material, Click **Yes** to complete.

Assign to Edit List

In this method, Type the Beam or Plate No's in the list below, Click **Yes** to finish.

Geometric Constant (Beta Angle)

When you assign a cross-section to any beam (beam or column) STAAD Pro will orient the cross-section in a way that it may not satisfy your Structural Case.

Example: - Assemble the following 3D Frame.

Note the orientation of the cross-section, and hence the orientation of local Y.

Your requirements now will be rotate the cross-section (A,B,C) in a way that it should have higher moment of inertia. Here it came's **Beta angle (β)** role.

When $\beta=90^\circ$ means, you will rotate the cross-section by 90° .

This command will work with Concrete and Steel Cross-sections. After Rotating the Columns A, B, C, the frame will look like the following:

Note:-


1. You can use any angle, not only 90° or -90° .
2. Angles in STAAD Pro are Absolute, and not relative, Meaning 45° is always 45° and not relative to the Current position of the Beam.



There are three ways to assign Beta Angle to Beams:

- From menu select **Commands/Geometric Constants/Beta Angle** (Following Dialogue will Appear).
- From General Page **Control/Property** Sub Page, from Data Area on the right, Click on the **Beta Angle** tab and You will see the following Dialogue.
- Double Click on the desired Beam. A dialogue box will appear, under the **Additional Info** Part, the current Beta Angle will be displayed.

Click Change Beta Button, and set the new Beta Angle.



Supports

Supports are most important for any structure. Without Supports, analysis may not run and STAAD Pro will produce error Message.

Following are the different types of Supports:

1. Fixed
2. Pinned
3. Fixed Butt,

Note:- The other types of Supports like Enhanced, Inclined, Foundation, etc.. Will be dealt in advanced Material.

1. Fixed

Fixed in STAAD Pro means there will be no movement in any direction, and no rotation around any axes.

There will be six reactions on this support, FX, FY, FZ, MX, MY & MZ.

Used most to model isolated footings.

2. Pinned

Pinned in STAAD Pro means there will be no movements in any direction, but there will be rotation around the axis.

There are 3 reactions only on this support FX, FY, FZ.

Used mostly in plane structure (2D geometry parallel to XY plane). If used in plane structure, there will be only 2 reactions FX, and FY (Which is Axial, and Shear respectively) as FZ will not be considered by the Structure itself. If you Want to use it in 3D geometry, study your case carefully, as it may not fit what you need.

3. Fixed Butt

This support is to used in case of releasing your fixed support, especially in 3D Frames. Simply supported can also be given by releasing all forces except FY.


You can release any of the following FX, FY, FZ MX, MY & MZ.

This will give the user the power to model the Structure case exactly.

How to assign Supports?

There are two ways to assign Supports to Nodes:

- **Using Menus,**




Select the required Nodes.

From menus select **Commands/Supports Specification**, then select one of the first three choices; Pinned, Fixed, Fixed Butt/ Spring.

For **Fixed and Pinned**, there will be no additional information, hence click Assign.

For **Fixed Butt**, you should select which of the 3 forces, and/or which of the 3 moments to be released.



Using Page Control,

For General Page Control, selected support sub-page.

Once you are there, the cursor will change to Node cursor automatically.

- Select the desired Nodes.
- From the Data Area, click Create.

A dialogue box will be displayed, pick the desired type of supports, and Click Assign.

Editing Supports

From the Selection toolbar, select Support Edit Cursors icon, select the support, to show the dialogue box of the support to edit it.

Another way would be to double click, the support definition in the Data Area, to show the dialogue box of the Support to edit it.

Specification

In specification, there are commands to define the structure more exactly.

For example, if there are truss members in space structure, we can define those particular truss members alone; hence they can sustain axial loads only.

Another example is, we can Release members for any reactions or moments at a particular joint.

a) Beam Release

The Nodes at the ends of each Beam, is always considered to be Rigid Nodes, hence there will be six reactions at each Node.

You can release any of the 3 forces (FX, FY, FZ) and/or 3 moments (MX, MY, MZ), in a member at the Start Node or at the End Node from.


- Select General Page Control, and Spec sub-page.

- Select the desired Beam, then Click Beam Button.

You can reach the same command using menus by selecting Command/Member Specification/Release. The dialogue box will appear;


Specify the following information:

- The **Release Type**, whether **Partial Moment Release**, or Release.
- The **location**, whether at the **Start**, or at the **End** of the Beam.
- Specify the **Release**, Choose the desired the desired check box.



Click

Assign.



Release will be shown in the member like this:

Editing Beam Release

1. After you apply the release you can change it, by **Double Clicking** the Beam, a dialogue box will appear, and under Releases you will see the Release current release Conditions:




Click Change Releases At Start or End, if the current release is at the star or at the end of the Beam.

The original release dialogue box will appear as we seen in t5he previous page, and you can change it to the desired release.

2. From the Selection toolbar, select Member Release edit Cursor icon, double-click the Release itself (and not the Beam), to show the dialogue box of the Release to edit it.
3. Another way Would to be Double-click on the Release from the Data area, to show the dialogue box and edit the Release.

b) **Editing Beam Release**

The Concept is same applied for plates. Here you can specify 3-4 Nodes instead of 2only.



c) **Truss Members**

If user defined the file as Truss Structure, all the Beams (by default) will take only axial loads only. Hence the Beams will not carry neither Shear nor Moment.

But if you define the Structure as Space or Plane, all the Beams a(by default) will carry axial, shear and moment.

Accordingly, if you have in Space, or Plate Structure a Truss, STAAD Pro will never know to deal with truss members, except to consider them as any other members, which means will carry axial, shear, and moment.

To let STAAD Pro treat truss members as special case, you have to specify that as specification.

From **General Page Control**, select **Spec** sub-page.

You can reach the same command using menus by selecting **Command/Member specification/ Truss**.

Select the Beam to be declared as true Members.

Click **Beam** Button, The **Beam Spec** dialogue box will appear, select Truss Tab.

Click **Assign**.

Note:- Likewise the **Member Tension or Member Compression** command can be used for members that can carry only tension or Compression members.

Members offset is used to offset the members in X,Y or Z directions.

Loads

Structural loads or actions are forces, deformations, or accelerations applied to a structure or its components.

Loads cause stresses, deformations, and displacements in structures. Assessment of their effects is carried out by the methods of structural analysis. Excess load or overloading may cause structural failure, and hence such possibility should be either considered in the design or strictly controlled.

Mechanical structures, such as aircraft, satellites, rockets, space stations, ships and submarines, have their own particular structural loads and actions.

Engineers often evaluate structural loads based upon published regulations, contracts, or specifications. Accepted technical standards are used for acceptance testing and inspection.

First Basic Loads called Primary Loads are given in to the Structure. Then Load Combinations are used which will combine a factored Primary Loads, simulating the design Codes combinations, which will generate the maximum shear/moments results.

Primary Loads

Primary Load is the base for the Loadings in STAAD Pro.

Each Primary Load should have a number (essential to STAAD Pro), and a Title (Optional for STAAD Pro, but important to the user).

You can left Title Empty, but later on, it will very difficult, to renumber what is this load, hence make sure always to type a good Title.

Primary Load Contains inside it all the individual loads which may act on:

- **Nodes,**
- **Beams,**
- **Plates.**

Load Combinations

Combination Load is the Primary Loads defined earlier multiplied by a factor.

The Number of the first load Combination will be next to the Primary Load Number. As an example, if the last Primary Load Number is 4 then the first load Combination number will be 5.

Example for the Load Combination is,

1 1.2 2 1.2 -> 1&2 are Primary loads and 1.2 is the factor.

Meaning is $1*1.2+2*1.2$.

Because STAAD Pro deals with the Primary Load Case number and not the title, give in the equation of the combination, only the primary Load case number.


Creating Primary Loads

➤ From the menus, select **Command/Loading/Primary Load**.

Or

➤ Go to **General Page Control**, and select **Load Sub-Page**.

a) If this the first time you invoke this sub-page, you will see the following dialogue box;



You can see that the Create New Primary

Load Case is highlighted and Existing Primary Load is dimmed, as it is not available now.

Leave the number to be 1, also leave Loading Type to be none, and type the Title of your load. Then enter OK. Proceed with giving the Loads.

b) If you want add existing load in to current ,


c) From the menus, select **Command/Loading/Moving Load Generation**.

Or

d) Go to **General Page Control**, and select **Load/Add Load Case/Load Generation Sub-Page**.

You will get the following screen:

Now you can select between the two choices to edit an existing load, or create a new one.




Note:-

If you want to create New Load Case,

- From the menus, select **Command>Loading/Primary Load**. Or
- Go to **General Page Control**, and select **Load/Add Load Case/ Primary Sub-Page**.

The following Button to be Appear,

- You can see the current load in 3 different places as below,



Primary Load Types.

After entering the loading screen you will find the following different types of load,

- **Self Weight,**
- **Member Load**
- **Element or Plate Load**
- **Joint Load**
- **Temperature Load,**
- **Wind Load**
- **Moving,**
- **Seismic Load**
- **Snow Load,**
- **Time Frequency**

Etc...

It is Preferable to select the desired Nodes, Beams or Plates prior to applying the load. This way you will be able to apply the load to multiple Nodes, Beams, Plates, Surfaces which will minimize your time.


STAAD Pro enables the user to specify the direction of each load using Global, Local, and Projected Methods. This Software is equipped with a self weight command, which can calculate self-weight of the structure based on cross-section, length and material density.




STAAD Pro can simulate a one way and two way slab loading directly on the beams carrying any slab.

Self-weight

- From the menus, select **Command/Loading/Primary Load**. Or
- Go to **General Page Control**, and select **Load/Add Load Case/ Primary Sub-Page**.
- Select **Load Case-1** , click **Add Button**
- From Add New : Load Items, Self weight to be default, Diagram to shown below
- By default **Y axis** is in the selection & **Factor** is **-1**, if you want to change setting change the Axis& Factor. Otherwise Click **Add & Close** button.
- Select **Self-weight** load as shown in the picture, Click **Assign to View**(because all Member must have their own Weight).






- Warning Message displays, click YES to assign Loads.

Member Load

Member Load are Loads applied to beams, columns, truss members, bracing members, Connection members, etc.,

- From the menus, select **Command/Loading/Primary Load**. Or
- Go to **General Page Control**, and select **Load/Add Load Case/ Primary Sub-Page**.
- Select **Load Case-1** , click **Add Button**
- From **Add New : Load Items**, Select **Member Load** ,the following Diagram to shown below



- In the above Picture specify the following parameters,
 - Specify the type of load whether concentrated, uniform, etc., give value of load and the distances (if applicable).
 - Specify the direction of Load ,
 - Click **Add** button

- Select the Beams to assign this Load, Click **Assign to Selected Beams** button, Click **Yes**.

FOLLOWING ARE THE TYPES OF MEMBER LOAD

Various types of Member Load are shown below,

- **Uniform Force,**
- **Uniform Moment,**
- **Concentrated Force,**
- **Trapezoidal**
- **Linear Varying,**
- **Area Load,**
- **Floor Load**

Etc.,

Uniform Force or Uniform Moment

From the picture shown above, Select Uniform Force or Uniform Moment (shown below uniform Force),

Specify the following Parameters shown below,

W1->Value of the load in currently selected units.

d1, d2 -> Distance of starting and ending points of the load from the starting node (Node A) of the member. If these values are zero, then the load is applied over the entire length of the member.


d3-> Perpendicular distance from the member's shear center to the plane of loading.

Direction->Click on the appropriate radio button to specify the direction of the load.

X, Y, Z indicate the direction in local coordinates;

GX, GY, GZ indicate the loads in global coordinates;


PX, PY, PZ indicate the loads along the projected length of the member in the corresponding global direction.



However, **d1**, **d2** and **d3** are still measured along the length of the member and not along the projected length.

Concentrated Force (or) Concentrated Moment

To specify a concentrated force or moment, select the *Concentrated Force or Concentrated Moment* tab. The data items are explained below.



P->Value of the load in currently selected units.

d1->Distance of the load from the starting node (Node A) of the member. If this value is zero, then the load is applied at the midpoint of the member.

d2->Perpendicular distance from the member's shear center to the plane of loading.

Direction->Click on the appropriate radio button to specify the direction of the load.

X, Y, Z- indicate the direction in local coordinates;

GX, GY, GZ indicate the loads in global coordinates;

PX, PY, PZ- indicate the loads along the projected length of the member in the corresponding global direction.

However, **d1** and **d2** are still measured along the length of the member and not along the projected length.

Trapezoidal

To specify a **trapezoidal load** on a member, select the *Trapezoidal* menu tab. The data items are explained below.

W1, W2-Starting and ending load values in currently selected units.


d1, d2-Distance of starting and ending points of the load from the starting node (Node A) of the member. If these values are zero, the load is applied over the entire length of the member.

Direction->Click on the appropriate radio button to specify the direction of the load.

X, Y, Z indicates the direction in local coordinates;

GX, GY, GZ indicates the loads in global coordinates;

PX, PY, PZ indicates the loads along the projected length of the member in the corresponding global direction.



However, **d1 and d2** are still measured along the length of the member and not along the projected length.

Examples for the Force Direction

- In the Following case of Beam, when you give loading in Y Direction or GY Direction, Sign will be Negative.
- In the Following case of Columns, when you loading in Global direction, it is positive GX, and when you give it in local direction it is Negative Y.
- Following is the illustration for the inclined beam. Vertical load will be Negative Projected Y direction and inclined load in the local negative y direction.

Note:-For projected direction, if the X-Y plane, then you have only PX & Py a possible directions for the loads to be applied in the same plane. Accordingly, that applies to other planes. Also, for uniform force, using the projected direction, the value

of the load will not be the input value, instead it will be the input value multiplied by the Sine or Cosine of the angle between the inclined Beam and Horizontal in the plane of Loading.

To verify, see the following example:

If you have the following case(frame in X-Y Plane):

The Angle between the inclined Beam and the horizontal is 53

Fig-1 If you apply a uniform force of -10KN/m over the beam length using PY direction, the value of the load will be -6 why? Because $\text{Cosine } 53=0.6$ and hence $10*0.6=6$

Fig-2 If you apply a force=10KN/M over full beam length using PX direction, the value of the load will 8.66, why Because $\text{sine } 53=0.79$ and $10*0.79=7.9$.


Linear Varying

To specify a linearly varying load on a member, select the *Linear Varying* tab. The load is applied over the entire length of the member. The data items are explained below.

W1, W2->For a linearly increasing or decreasing load, enter the values of force $W1$ at the start of the beam and $W2$ at the end of the beam in currently selected units.

W3->For a triangular load distribution, enter the value $W3$ of the force in the middle of the beam.

Direction->Select the direction of the force in local coordinates from the radio buttons X, Y or Z.




Area Load


This allows the user to apply area (panel) load which will be distributed

on surrounding beams based on a one way distribution.

- From the menus, select **Command/Loading/Primary Load**. Or
- Go to **General Page Control**, and select **Load/Add Load Case/Primary Sub-Page**.
- Select **Load Case-3**, click **Add Button**
- From **Add New : Load Items**, Select **Area Load**, the following Diagram to shown below




- Enter Pressure Value in the Current units,
 - **Direction**->Click on the appropriate radio button to specify the direction of the load.
 - **Local Z** indicates the direction in local coordinates;
 - **GX, GY, GZ** indicates the loads in global coordinates;
- Floor Load**




This option allows the user to apply a panel load which will be distributed on surrounding beams based on a two way distribution.

- From the menus, select **Command/Loading/Primary Load**. Or
- Go to **General Page Control**, and select **Load/Add Load Case/Primary Sub-Page**.
- Select **Load Case-3**, click **Add Button**

- From **Add New : Load Items**, Select **Floor Load** ,the following Diagram to shown below



- Enter Pressure Value in the Current units
- Select the Range in X or Y or Z, or by Group by clicking the Corresponding Radio Button.
- **Direction**->Click on the appropriate radio button to specify the direction of the load.
- **GX, GY, GZ** indicates the loads in global coordinates;
- Range:- Type the deflection range in the X , y, z & **Minimum & Maximum Range** in current units,
- **One Way Distribution**:- Check this option used where Load to be Distributed in One Way (Slab).



Select the Node no from Default List Box by clicking the down arrow button,


Here no need to select any Beam before applying this Load.

Example:-

To apply the floor load like following,

- From the menus, select **Command/Loading/Primary Load**. Or
- Go to **General Page Control**, and select **Load/Add Load Case/ Primary Sub-Page**.
- Select **Load Case-3** , click **Add Button**

- From **Add New : Load Items**, Select **Floor Load**, the following Diagram to shown below



- Type **-5 in load Value (for Pressure)**,
- Define the **Y force** effectiveness which will act in the Global Y direction. In our example force is affecting so that the range from 30'.
- Define the **X force** effectiveness range which will act in the Global X direction. In our Example will from 30'.
- Define the **Z force** effectiveness which will act in the Global Z direction,. In our example the will be from 30'.
- Click **Add & Close button**.


Load to be automatically assigned to structure.

When you don't give X range or Z range, and give only y range, the force will distribute on the full floor.

Plate Load

Plate Loads are Loads applied to Plates.

- From the menus, select **Command/Loading/Primary Load**. Or
- Go to **General Page Control**, and select



Load/Add Load Case/ Primary Sub-Page.

- Type the title, Click **Add**
- Select **title given in the previous Step**, click **Add Button**
- From **Add New : Load Items**, Select **Plate Load**, the following

Diagram to shown below

The Plate Load tab offers several sub-menu options as shown below. These options are discussed in the following,

a) Pressure on Full Plate


Use this option to define a pressure load that acts on the full surface of an element. (To define a pressure load that acts on a small part of an element, see the Partial Plate Pressure tab that is described in the coming pages).

Load:-W1 is the variable using which the pressure value is defined, in pressure units.

Direction:-The load may be applied along the local Z axis, or along one of the global X, Y or Z axes (GX, GY, GZ)

b) Concentrated Load

Use this option to define a concentrated load that acts at a specific point within the boundary of an element. If a load acts at a node point of an element, it is advisable to apply it using the Nodal Load option described in earlier pages.



Load->The magnitude of the load is specified in the box alongside Force.

X and Y define the location of the load, in terms of the distance from the origin of local X and Y axes of the element.

Direction:-The load may be applied along the local Z axis, or along one of the global X, Y or Z axes (GX, GY, GZ).



c) .Partial Plate Pressure Load

To specify a uniform pressure load on the entire element or on a user specified portion of the element, use this facility. The data items are explained below:

Load->The element pressure (force per unit area) or concentrated load (force unit). For concentrated load, the values of $X2$ and $Y2$ must be omitted, while $X1$ and $Y1$ must be specified.

$X1$, $Y1$, $X2$, $Y2$ ->For element pressure (force per unit area), these values represent the coordinates of the rectangular boundary on which the pressure is applied. If $X1$, $Y1$, $X2$ and $Y2$ are all zero, the pressure is applied over the entire element. If $X1$ and $Y1$ are specified but $X2$ and $Y2$ are omitted, then $W1$ is treated as a concentrated load.

Direction-> GX , GY , GZ represent the global X , Y , and Z directions along which the pressure may be applied. *Local Z* indicates that the pressure is applied normal to the element in the local Z direction.



d) Trapezoidal


To specify a trapezoid ally varying pressure load on a plate, select the *Trapezoidal* tab as shown below. The load is applied over the entire element in the local Z direction, varying along the positive local X or Y direction. The data items are explained below.

Direction of Pressure->GX, GY and GZ represent the global X, Y, and Z directions along which the pressure may be applied. Local Z indicates that the pressure is applied normal to the element in the local Z direction.

Enter the pressure intensity F1 at the lowest local coordinate location (start) and the intensity F2 at the highest local coordinate location (End). Start and End are defined based on the positive direction of the local X-axis or local Y-axis.

Variation along element:-Define the direction in which the pressure varies as either the local X or Y direction or choose the joint option which is discussed next.


Joint:-Check the joint option to apply different values of pressure at different nodes of the plate element. When checked, the dialog box will change as shown below. Apply different values of pressure in the edit boxes for the different nodes.



e) Hydrostatic


To model loads due to hydrostatic pressure on one or more adjacent elements, select the *Hydrostatic* tab as shown below. The Hydrostatic load is converted to Trapezoidal loads on the elements. The load is applied over the entire area of the element. The data items are explained below.

Force:-Enter value of the load at the minimum and maximum global axis in current units. For example, to model a retaining wall with soil pressure, W1 is the force at the bottom of the wall and W2 is the force at the top of the wall.




Interpolate along Global Axis:-Specify the global axis (X, Y, or Z) along which the load should vary from W1 to W2. For example, the load would vary along the Y axis on a vertical retaining wall. **Select Plate(s):-**Unlike other load definition options, we must select plate(s) for this option to become active. Click on this button to select plate(s).

Click on the Select Plates button shown in the previous figure. The following dialog box will appear. Select all the plates of a wall on which we wish to apply the hydrostatic load.




The Selected Members dialog box will now appear as shown below. Click on Done. The Hydrostatic dialog box will re-appear.



Direction of pressure:-Specify the direction of design pressure as Local Z axis or global axes (GX, GY or GZ) and click on Add. This will assign the linearly varying hydrostatic load on all the selected elements.

f) Element Joint Load

To specify a varying pressure at each joint on a plate, select the Element Joint Load option as shown below. The data items are explained below.



Joint Load Data:-Choose Three Noded Facet / Four Noded Facet depending on whether the plate element is 3 noded or 4 noded.

Direction:-The load may be applied along the local Z axis, or along one of the global X, Y or Z axes (GX, GY, GZ).

Add:-After defining a load click the *Add* button to add this under the current load case in the *Loads* dialog box.


Load Combinations

a) Manual Combination

Manual combination is one in which user created it, and not STAAD Pro. Here,

- User Specifies the factors which will be multiplied by the Primary Loads &
- User specifies how many combinations are needed.

1. From the menus, select **Commands/Loading/Load Combination**
2. From **General Page Control**, click **Load definition**, click **Load Case Details**, Click **Add**. The following dialogue appears,



3. From the above dialogue select **Define Combinations**.
4. Select **Loads** to combine, click **>** button, Click **Add** or
5. To **combine all Loads** Click **>>** button, Click **Add**.
6. To **remove a load from the combination** click **<** button or
7. To remove all loads & recombine new, Click **<<** button.

Automatic Combination

Automatic Combination is a combination:

- Created by STAAD Pro according to specific Codes.
- STAAD Pro Will specifies the factors which will be multiplied by the Primary Loads.
- STAAD Pro specifies how many combinations are needed.


As pre-requisite user should take care of the following points;

- When creating a new Primary load, Select Loading Type from the pop-list, which contains Dead, Live, Roof Live, Wind, Seismic, Snow, Fluids etc.,
- Don't mix up the Loading Type with the Title.


- For an example, We select here Load Case 1 is **Dead**, Load Case2 is **Live Load(Beam)**, Load Case 3 is **Live (Plate)**,

After Finished giving Primary Loads,

1. From the menus, select **Commands/Loading/Load Combination**
2. From **General Page Control**, click **Load definition**, click **Load Case Details**, Click **Add**. The following dialogue appears,



3. From the above dialogue select **Automatic Combinations**.
4. Then Select the **Load Combination Category**, Which will dictate the number of combinations, and the factors used.
5. Click **Generate Loads** button, the dialogue box will appear:



6. To **remove a load from the combination** click **<** button or
7. To **remove all loads & recombine new**, Click **<<** button.
8. After you are done, click **Add** Button.

Now automatic Load Combination will add based on the Primary Loads in the Structure & based on Type of Code.

STAAD ANALYSIS

CHAPTER - VI

Model Analysis.

This Chapter covers:

- Analysis & Analysis Types
- Perform analysis Command
- P-Delta Analysis Command
- Perform imperfectionAnalysis Command
- How to run the Program.
- Checking for Error
- Post processing overview
- Node Results
- Beam Results
- Animation
- Creating reports
- Printing Reports
- Other methods to check the results.

In the Previous Chapter, we have learned how to assign Properties, Constants, Supports, Loads & Load Combinations to the Structure.

So that we are completing modeling part. Next what we have to do is analyzing of the Structure in the Staad.

In this Chapter We have to learn about analysis & Types of Analysis. Same time we learn how to Check error & about Post Processing .

About Analysis

In order to obtain the **displacements, forces, stresses and reactions** in the structure due to the applied loads, the model has to be analyzed. If the **pass-fail** status of the members and elements per the requirements of steel and concrete codes is to be determined, that involves a process called design. Both these processes are launched using the Run Analysis option from the Analyze menu.

Elastic analysis method is used to obtain the forces and moments for design. Analysis is done for the primary and combination loading conditions provided by the user. The user is allowed complete flexibility in providing loading specifications and using appropriate load factors to create necessary loading situations. Depending upon the analysis requirements, regular stiffness analysis or P-Delta analysis may be specified. Dynamic analysis may also be performed and the results combined with static analysis results.


Analysis Types

Analysis can be classified based on Various type of analysis are shown below,

1) Stiffness Analysis / Linear Static Analysis

2) Second Order Static Analysis

- P-Delta Analysis
- Perform imperfection Analysis
- Multi Linear Spring Support



- **Member/Spring Tension/Compression only**

3) Dynamic Analysis

- **Time History**
- **Response Spectrum**

Introduction:

Following are the Analysis types in STAAD Pro

- **Static Analysis**
- **Dynamic Analysis**

Static Analysis can be either

- **Perform Analysis (Linear Analysis)**
- **P-Delta Analysis**
- **Perform imperfection Analysis**

Dynamic Analysis can be either

- **Time History**
- **Response Spectrum**

Note:- We will cover only static analysis and their requirements in this book. Other analysis types are dealt in advanced chapters.

Analysis command is a single line command, which will be added to your input file, and not the execution command. Analysis command will tell STAAD Pro what is the desired analysis type you want to use to get your results.

Stiffness Analysis

The stiffness analysis implemented in STAAD is based on the matrix displacement method. In the matrix analysis of structures by the displacement method, the structure is first idealized into an assembly of discrete structural components (frame members or finite elements). Each component has an assumed form of displacement in a manner which satisfies the force equilibrium and displacement compatibility at the joints.


Structural systems such as slabs, plates, spread footings, etc., which transmit loads in 2 directions have to be discretized into a number of 3 or 4 noded finite elements connected to each other at their nodes. Loads may be applied in the form of distributed loads on the element surfaces or as concentrated loads at the joints. The plane stress effects as well as the plate bending effects are taken into consideration in the analysis.

Perform Analysis:


Following is the nature of Perform Analysis command:

- Displacement of Nodes is minimal that will not cause any secondary loading.
- Deflection of Beams is so minimal that will not cause any secondary loading.
- The structure will be analyzed once.
- The results of the first iteration will be considered the Analysis results.

Select **commands/Analysis/Perform Analysis**, the following dialogue box will appear:



- Select one of the **Print Options**, and click **OK**. Or
- From the **General page control**, select **Analysis/Print**, the following dialogue box will pop-up automatically:



Select one of the Print Options, and click Add. Close the box.

Print Options:

The print options in both dialogue boxes are not related to the analysis results generation, but instead they are some add-on print option for load and static check.

No Print:-It will do the Analysis and don't print any additional information.

Load Data:- It will do the Analysis and will print the primary load cases, which of the Nodes/Beams/Plates the primary loads are affecting, the value, and the location.

Statics Check: In addition to Analysis, it will print two sets of summations:

- The summation of the applied loads, and moments around center of gravity.
- The summation of the reaction loads, and moments around center of gravity. Also it will print the maximum displacement as movement and rotation.

Statics Load: Like statics check, plus External and Internal joint loads for the supports.

Mode Shape: Only for Dynamic Loading

Both: Load Data + Statics check.


All: load Data + Statics check + statics Load

P-Delta Analysis:

- It is the second-order stability analyses.
- It is a Multi-iterative analysis. Following is the representation of loading:

If the lateral load and the vertical load are working simultaneously, the P-data Analysis will work like this:

- Calculate the Primary displacement of Nodes based on the external loads (as discussed in the perform Analysis).
- Due to the Displacement of the Nodes, **STAAD Pro** will calculate the second order loadings.
- P will be revised to show the new value of loading (the original external the second order loadings).
- The location of P will be revised also.



- The new system is ready for iteration.

The Number of Iterations specified by the user, and/or the convergence value will stop the analysis engine from doing another iteration.


Convergence is the tolerance value, which the user will set as a reference, if the displacement of Nodes is less than this value the P-Delta Analysis will stop.

It will look like following illustration:

Select **Commands/Analysis/P-Delta Analysis**, the following dialogue box will appear:

- Specify the **Number of Iterations**.
- Click on the **Converge value** and specify it.
- Select **Print Options**, and click **OK**.

Alternatively, you can select from the **General page control->Analysis/Print->Analysis** sub-Option. Then choose **P-Delta Analysis**. Click **Add**, and then **close**.



Note:

Several codes like ACI 318, LRFD, and IS456-2000 recommends the using of the P-Delta Analysis instead of the perform Analysis.

Because Perform Analysis command will not generate exact values for the shear/moment, but instead approximate value, hence user should magnify the moments by a factor to compensate the approximation. It can be only applied on Beams, and not Plates.

Perform imperfection Analysis:

With P-Delta Analysis Staad Pro took care of the secondary loading caused by the Displacement of the Nodes. But deflection of Beams was not considered.

Perform imperfection Analysis takes care of both secondary loading caused by Displacement of the Nodes, and geometric stiffness correction caused by Deflection of Beams.

Suitable for long spans beams with high deflection. Deflection is considered in the Analysis, rather than to be checked for in the design.

It is a multi-iterative analysis. Following is the Illustration of loading:

The Perform imperfection analysis will work like this:

- Calculate the primary displacement of Nodes based on the external loads

- Due to the Displacement of the Nodes, Staad Pro will calculate the second order loading, and due to Beam Deflection STAAD Pro will calculate the stiffness Correction
- P will be revised to show the new value of loading (the original external load secondary loading +stiffness correction.)
- The location of P will be revised also.
- The new system is ready for next iteration.

The number of iterations specified by the user will stop the analysis engine from doing next iteration.

Select **Command/Analysis/Perform imperfection analysis**, the following dialogue will appear:

- Specify the number of iteration.
- Select Print options, click OK.

Alternatively, from the **General Page Control**, select **Analysis**, Click **Perform imperfection analysis** tab.

The following dialogue will appear:



Note:-

In all the cases the line of the analysis type will be added to the input file, and you can see that Data Area as follows

Note:- p-Delta analysis and imperfection analysis will work only with structures that can transfer the axial force loads from one story to another.

After giving analysis command,

Add Command/Post-analysis Print/Analysis results to view the Analysis results in output file after running the problem.




Run the Program

Any Program should be runner to get result.

After Analysis Command was added to the input file, then it will be ready for execution.

- From the menus select **Analyze**, Click **Analysis**.



- By using short cut key **Ctrl +F5**.

Now the entire input file will be sent to STAAD Pro Analysis Engine. Now Staad Analysis Engine will reads the input file from left to Right and from Top to Bottom & Verify the following,


- Whether all the Commands are given.
- Whether the Structure is Stable or not.
- Whether Staad Pro Syntax has been followed correctly or Not.

First Case:- If there no error in the Program

If all the Steps are given right, Staad Pro will run the Program and the Screen will look like this;

In the below dialogue, you can see that Staad Pro will go through each step and perform calculation. Also it shows "Analysis Completed Successfully". Then it creates the Following Files;

- **Displacement file, filename.dsp**
- **Reaction File, File name.rea**
- **Section Force file, filename.bnd**
- **Section Displacement File, filename.scn.**



```

...Factor at equation=      3000 of =      3330      4: 2:26
...Subspace size =          107                      4: 2:26
...Eigensolution at Step=    9 # converged    65      4: 2:38
Eigensolution done, # of non zeros= 306171          4: 2:39
++ Finished Advanced Solver Eigen.                  13 sec
++ Calculating Member Forces.                        4: 2:39
++ Analysis Successfully Completed ++
++ Processing Element Forces.                        4: 2:39
++ Processing Element Corner Forces.                 4: 2:39
++ Processing Element Stresses.                     4: 2:39
++ Creating Displacement File (DSP)...                4: 2:39
++ Creating Reaction File (REA)...                   4: 2:39
++ Creating Mode Shape File (MSH)...
++ Calculating Section Forces
++ Creating Section Force File (BMD)...               4: 2:39
++ Creating Section Displace File (SCN)...           4: 2:39
++ Creating Element Stress File (EST)...             4: 2:39
++ Creating Element JT Stress File (EJT)...          4: 2:39
++ Creating Element JT Force File (ECF)...           4: 2:39
++ Done.                                             4: 2:39

0 Error(s), 3 Warning(s)

** End STAAD.Pro Run Elapsed Time =    14 Secs
** Output Written to File:
   F4-SimplySupport Bridge.anl


 View Output File
 Go to Post Processing Mode
 Stay in Modelling Mode
  
```

Finally, Staad Pro will create filename.anl which contains the output that you can read using output editor.

- ❖ **To View Output file:-** when you choose this option you will get Staad output editor screen showing results.
- ❖ **To get Post Processing Mode:-** with this option you will be directly taken to the post Processing mode, to view the results, which contains tables and Graphical output in a Very Professional way.
- ❖ **To stay in Modeling Mode :-**When you choose this option you will stay at the Modeling Mode, and later you can view the output file, or go to the Post Processing Mode at your convenience.

Second Case: if there is any error in the Program

If Staad Pro finds any type of error it will show the following dialogue box:



In this dialogue box, you can see That Staad Pro has found some error and it cannot proceed further.

It gives you two choices to select from:

- **To View Output file:-**(Error in analysis. check output(.Anl)file). This option will take you directly to the Staad output editor to view where your mistake was.
- From the above message you can identify the error, hence go to the input file and correct it.
- **To stay in Modeling mode:-**When you select this option you will stay at the Modeling Mode, and later you can view the output file, and find the error message.

Post Processing


Post Processing Mode is where you see your results, print them or prepare a full report for a selected member.

Staad Pro will produce all the results, through we didn't specify what type of results we need in our input file.


Staad Pro are graphical using colors in an attractive way, tavles with fonts, and grid (which user can customize), and all results can fit in the inkjet/laser printer.

Introduction

There are three ways to go Post Processing Mode:



- From Menu Select **Mode/Post Processing**.
- From **Mode** tool Bar, Select the **Post Processing** icon
- After you finish run analysis command, the dialogue box will give you an option to go directly to Post Processing Mode.




Then the following dialogue will appear;

User should Specify the desired loads to see the results for see here that STAAD Pro assumed all loads are wanted.

If you don't want any loads(click & drag, or use Control key), and click the left single Arrow, you Will get the following;


Click Ok , and you will be taken to the Post processing Mode.



1. **Node results:** as soon as you enter, you will see Node Displacement Page.

You will see the screen cut in to Three Parts:

- The **Node Displacement** table.
- The Beam Relative Displacement Detail Table.
- The Node Displacement diagram screen at the Center of Screen.



- a. **Node-> Displacement:-** on the right side of the Screen, under Node Displacements, You will see All & Summary tabs.

All:-in this tab you will see for each Node, and for each Load case (L/C) selected by the user:

- The movement of the Node in the **X, Y & Z** direction.
- The resultant movement of the Node.
- The Rotational of Node around x,y & Z measured in Radians.

Following is an Example:

Node	L/C	Horizontal			Resultant	Rotational		
		X in	Y in	Z in		rX rad	rY rad	rZ rad
1	1 FREQUENC	0.000	0.000	0.000	0.000	0.000	0.000	0.000
2	1 FREQUENC	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3	1 FREQUENC	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4	1 FREQUENC	0.000	0.000	0.000	0.000	0.000	0.000	0.000
5	1 FREQUENC	0.000	0.000	0.000	0.000	0.000	0.000	0.000
6	1 FREQUENC	0.000	0.000	0.000	0.000	0.000	0.000	0.000
11	1 FREQUENC	1.463	-0.159	3.504	3.800	0.006	0.000	-0.000
12	1 FREQUENC	1.463	-0.161	3.501	3.797	0.007	0.000	-0.000

Summary:-

In this Tab you will see,

- The Maximum & minimum movement in the X,Y and Z table summary directions, and which load case caused it.(maximum is the largest number in positive, and minimum is the largest is the negative.
- The maximum and minimum rotation around X,Y, and Z, and which load case caused it.

Following is the example.

Beam	L/C	Dist m	x in	y in	z in	Resultant in
1	1 FREQUENC	0.000	0.000	0.000	0.000	0.000
		2.528	-0.142	0.021	-0.483	0.504
		5.056	-0.028	0.004	-0.431	0.432
		7.584	0.094	-0.014	-0.171	0.196
		10.112	0.000	0.000	0.000	0.000
2	1 FREQUENC	0.000	0.000	0.000	0.000	0.000
		2.500	-0.133	-0.000	-0.497	0.515
		5.000	-0.004	-0.000	-0.469	0.469
		7.500	0.119	-0.000	-0.213	0.244
		10.000	0.000	0.000	0.000	0.000
3	1 FREQUENC	0.000	0.000	0.000	0.000	0.000

Beam Relative Displacement Detail

All Relative Displacement

In this tab you will see for each Beam, and for each load case selected by the user, the movement in the x, y & Z direction of the starting Node and the Ending Node, and

three inter-mediate points inside the Beam(Equally spaced), and finally the absolute Resultant movement.

Following is an Example.

Max Relative Displacements

In this tab you will see for each Beam, and for each Load Case selected by the user, the maximum movement of the Beam and where it occur within the Span of the Beam in the X, Y & Z direction.

Also you will see the absolute maximum movement in the Three Directions, and where it occurs within the Span.

Finally, you will see the Span/Max ratio, As an example, assume that a Beam with 4m Long made 14.861 mm Displacement, so, the Span/max will be $4/0.014861$ the results is 269. Following is an example:

Beam	L/C	Dist m	Fx kg	Fy kg	Fz kg	Mx kip-in	My kip-in	Mz kip-in
1	1 FREQUENC	0.000	-192.42712E	47558.852	-61292.113	-906.088	32215.887	19283.7
		2.528	-186.90103E	43474.347	-56433.052	-906.088	19300.377	9295.1
		5.056	-181.37494E	39389.842	-51573.995	-906.088	7451.032	205.1
		7.584	-175.84884E	35305.338	-46714.934	-906.088	-3332.147	-7989.1
		10.112	-170.32275E	31220.833	-41855.874	-906.088	-13049.161	-15288.1
2	1 FREQUENC	0.000	25000.800	52773.264	-58227.326	-8.548	31518.506	20541.1
		2.500	29806.101	47967.965	-53422.026	-8.548	19405.086	9611.1
		5.000	34611.401	43162.665	-48616.726	-8.548	8334.370	-275.1
		7.500	39416.700	38357.365	-43811.427	-8.548	-1693.642	-9120.1
		10.000	44222.000	33552.065	-38996.127	-8.548	-10670.052	-16924.1



both

Node Displacement Diagram

From the View Tool bar, select the required load case to see result:





Maximize the screen to get the following diagram:



From the menus select results/View Value, and you will the following Screen:

Select Ranges tab Choose All.

Select Node tab, you will see the following Screen.



You can see any one from **Global-X, Global-y & Global-Z & Resultant**.


Click Annotate button.you will see the following,

Note:-

You will see that deflected shape is not clear as above.So you have to change the scale.


For that follow the Procedure.

Click Scale icon on the toolbar. you will see the following screen.



Change the value of Displacement Scale.

You will See the picture more clearly now as shown.



Node

When you click this option you will see the following Screen:

Support reaction table at the right side. Support reaction in the middle.

Node	L/C	Horizontal	Vertical	Horizontal	Moment		
		Fx kN	Fy kN	Fz kN	Mx kip-in	My kip-in	Mz kip-in
1	1 LOAD CAS	-358.192	-1305.821	-191.799	0.000	0.000	0.000
	2 LOAD CAS	18.525	132.734	18.351	0.000	0.000	0.000
	3 LOAD CAS	38.174	251.793	37.837	0.000	0.000	0.000
	4 LOAD CAS	125.338	781.620	122.665	0.000	0.000	0.000
	5 LOAD CAS	-2637.290	-8895.850	-1110.656	0.000	0.000	0.000
2	1 LOAD CAS	-11.114	-11.545	-1.254	0.000	0.000	0.000
	2 LOAD CAS	-387.381	-812.143	-94.520	0.000	0.000	0.000
	3 LOAD CAS	-1.030	180.362	18.823	0.000	0.000	0.000

All

In this tab you will see for each support, for each load case selected by the user, 6 reactions **FX, FY, FZ, MX, MY, and MZ** as shown on the previous page:

Summary

In this tab you will see the maximum and Minimum **FX, FY, FZ, MX, MY, and MZ** and on which supports took place, and which of the selected load cases has caused them.

	Node	L/C	Horizontal	Vertical	Horizontal	Moment	
			Fx kN	Fy kN	Fz kN	Mx kip-in	My kip-in
Min Fy	29	5 LOAD CAS	-2744.374	-11282.958	-226.531	0.000	0.000
Max Fz	7	5 LOAD CAS	-2637.300	8895.894	1110.652	0.000	0.000
Min Fz	42	5 LOAD CAS	-2637.292	8895.878	-1110.659	0.000	0.000
Max Mx	1	1 LOAD CAS	-358.192	-1305.821	-191.799	0.000	0.000
Min Mx	1	1 LOAD CAS	-358.192	-1305.821	-191.799	0.000	0.000
Max My	1	1 LOAD CAS	-358.192	-1305.821	-191.799	0.000	0.000
Min My	1	1 LOAD CAS	-358.192	-1305.821	-191.799	0.000	0.000
Max Mz	1	1 LOAD CAS	-358.192	-1305.821	-191.799	0.000	0.000


Envelope

In this tab you will see find the maximum positive and the maximum negative **FX, FY, FZ, MX, MY, and MZ** on each support, and which of the selected load case caused them.

Node	Env	Horizontal Fx kN	Vertical Fy kN	Horizontal Fz kN	Moment Mx kip-in	Moment My kip-in	Moment Mz kip-in
1	+ve	125.338	781.620	122.665	0.000	0.000	0.000
1	-ve	4 LOAD CAS -2637.290	4 LOAD CAS -8895.850	4 LOAD CAS -1110.656	-	-	-
2	+ve	12.112	1077.327	133.191	0.000	0.000	0.000
2	-ve	4 LOAD CAS -3041.895	4 LOAD CAS -5408.652	4 LOAD CAS -532.148	-	-	-
3	+ve	12.411	1111.115	138.526	0.000	0.000	0.000


Node Reaction Diagram

Select the desired load case for which you have to see result using View toolbar:



You can see cut section and other commands to see Support reactions for a particular bay or node.

You will see the following diagram when maximize the screen:



Beam Results

Beam->Forces


When you click **Beam** tab in page control on the left you will get the follow screen:

Beam	LIC	Node	Fx kN	Fy kN	Fz kN	Mx kip-in	My kip-in
1	1 LOAD CAS	1	0.000	-2.493	-0.177	-2.092	2.411
1	2	2	0.000	2.493	0.177	2.092	2.364
2	1 LOAD CAS	1	0.000	3.097	-0.000	0.094	0.000
2	2	2	0.000	3.575	0.000	-0.094	0.002
3	1 LOAD CAS	1	0.000	-0.010	0.000	-0.132	-0.003
3	2	2	0.000	0.010	-0.000	0.132	-0.002
4	1 LOAD CAS	1	0.000	-0.346	0.002	0.473	-0.027
4	2	2	0.000	0.346	-0.002	-0.473	-0.025
5	1 LOAD CAS	1	0.000	-20.354	-1.236	-16.828	16.978
5	2	2	0.000	20.354	1.236	16.828	16.358
7	1 LOAD CAS	1	0.000	-0.043	-0.002	-0.031	0.021
7	2	2	0.000	0.043	0.002	0.031	0.022
2	1 LOAD CAS	2	0.000	-3.838	-0.177	-0.899	2.365
2	3	3	0.000	3.838	0.177	0.899	2.413
2	2 LOAD CAS	2	0.000	3.362	-0.000	0.014	0.003
2	3	3	0.000	3.310	0.000	-0.014	0.001
3	1 LOAD CAS	2	0.000	0.002	0.000	-0.015	-0.002
3	3	3	0.000	-0.002	-0.000	0.015	-0.002
4	1 LOAD CAS	2	0.000	0.134	0.002	-0.006	-0.024
4	3	3	0.000	-0.134	-0.002	0.006	-0.026
5	1 LOAD CAS	2	0.000	-29.335	-1.190	-7.753	15.956
5	2	3	0.000	29.335	1.190	7.753	16.155

All

In this tab you will see for each Beam, for each load case selected, for each Node at the ends of the Beam, the 5 Reactions FX, Fy, FZ, MX, My & MZ.


In this tab you will see the maximum and minimum FX, FY, FZ, MX, MY, & MZ and on which Node of each Beam, and which of the Selected load Cases has caused them, as seen below:



Envelope

In this tab you will find the maximum positive and the maximum negative FX, FY, FZ, MX, MY & MZ on each Node of each Beam, and when of the selected load case caused them.


See the below table as an example,



Beam Force Diagram


Select the desired load case for which you have to see result.

Maximize the screen & you will see the BMD about Z direction by default:



You can change the Scales of the diagram, as explained previously:

result scales		
Bending Y :	3500	kip'in per ft
Bending Z :	3500	kip'in per ft
Shear Y :	53.3787	kN per ft
Shear Z :	53.3787	kN per ft
Axial :	266.893	kN per ft
Torsion :	12	kip'in per ft
Displacement :	12	in per ft
Beam Stress :	60000	psi per ft
Mode Shape :	1.2	



You can also values of BMD by choosing from the menu Results/View Value.

Annotation - EXAMP06 - Whole Structure

Ranges Beam Results Node Reactions

None

All

View

Group

Property

Ranges Nodes:

Beams:

Remove All Annotate Close

Annotation - EXAMP06 - Whole Structure

Ranges Beam Results Node Reactions

Bending Ends Maximum Mid point

Shear Ends Maximum Mid point


Axial Ends

Displacement Max Resultant

Combined Bending and Axial Stress Ends Maximum Mid point









Remove All Annotate Close

Select the required Bending & Shear values from Beam Result tab. Click **annotate** to see the result like this .



Note:-

1. You can also see **BMS/SFD** in various directions as explained below by clicking on the respective button **ON/OFF**.

-  - To View the Axial Force.
-  -To view the Shear Force in Y direction.
-  -To view the Shear force in Z direction.
-  -To view Bending movement about X direction (torsion).
-  -To View Bending Movement above Y direction.
-  - To Bending movement in Z axis.
-  -To View bending Stress.
-  -to Deflection.


2. Likewise you can see Beam Stress also.

EXAMP06 - Beam Combined Axial and Bending Stresses:							
All Max Stresses Profile Stress Points /							
Beam	L/C	Dist m	Corner Stress				Max C ps
			Corner 1 psi	Corner 2 psi	Corner 3 psi	Corner 4 psi	
1	1 PRESTRES	0.000	0.000	0.000	0.000	0.000	0.000
		1.500	0.000	0.000	0.000	0.000	0.000
		3.000	0.000	0.000	0.000	0.000	0.000
		4.500	0.000	0.000	0.000	0.000	0.000
		6.000	0.000	0.000	0.000	0.000	0.000
2	2 POSTSTRE	0.000	0.000	0.000	0.000	0.000	0.000
		1.500	0.000	0.000	0.000	0.000	0.000
		3.000	0.000	0.000	0.000	0.000	0.000

Beam->Graphics

This is Graphical result for a Particular member you select.

When you click the sub-page of the Graphs in Page control the following will be displayed:



From the View Toolbar select the desired load case.

It will display for the selected Beam, for the selected load case:

- Bending moment Diagram(moment around Z-Z)
- Shear Diagram (Shear to Y-Y direction)
- Axial Load Diagram.

Note:- Right click on any of the above result diagram, and Choose Diagrams. Pick any one diagram and see the Result.

3. Animation

When you click this page control menu on the left, you will see the following box:

See the Diagram type from the following list:

- **No Animation:-**
(default option)
- **Deflection:-**

(Means the movement of the Nodes)

- **Section Displacement:-**

(Means the movement of the Nodes, and Deflection of the Beams)

Set the Animation Setup through changing the following

- **Extra Frames:-**


If you want frames than the needed number in order to enhance the animation.

- **Target FPS (Frames Per Second):-** Change the value to increase/ decrease the Speed of the animation.

Click OK, to see the Animation.

Note:-

- You can press **F12** while animation running to see it in full Screen.
- Press Esc key in the keyboard to stop animation & return to old Screen.




4. Reports

It is a beautiful way of getting results printed out.

It will produce elegant-good-looking reports, which take advantage of the colors of inkjet, and to include the geographical and tables in same report.


- Click **Reports** in page control menu on the left & you will get the following Screen. Or
- From the **Print Toolbar**, Click **Report Setup** icon. Or
- From menus, Choose File/Report Setup, and you will see the Following Screen.



Items Tab:-

In this tab you will select what are the content of the report from the input data, output results, and Pictures.

- From the available pop-up list, select the desired item.



Input:

From the input, you will have a list of the Input data at the left. Select the input data you want to include it in your report. Then click the one arrow button (by default the job is included in the report)


Output

From the output, the same thing applies. You will see a list at the left. Select the output tables you want to identical to the tables we covered in this module. Then click the one arrow button.

Pictures:-

In order to include pictures in your report, You should take the pictures before.

- From the **Print Toolbar**, Click **Take Picture**.
- From menus choose **Edit/Take Picture**.
- The following dialogue box will appear:



Type in the ID field, which is the name of the Picture. The Caption is generated automatically from the status of the results viewing on the screen.

If you create several pictures, and you selected the Pictures option in the pop-up list, you will find these pictures listed for you. Select the desired pictures and click one arrow button.




-After you selected the input, output & Pictures, you may want to rearrange the sequence of the data. You can use the two arrows at the right side of the dialogue box. The arrow pointing up will take any item one step up in the list; hence this data will appear in the starting pages. The arrow pointing down will take any item one step down in the list; hence this data will appear in the ending pages.


Load cases Tab

By default the output results will be shown for all load cases (primary & Combination).

In this dialogue box you can specify the load Case to be included in your Report.



In this tab, user specifies whether the report should contain results about all Nodes, Beams, and Plates, or only some of them.




Picture Album Tab:-

In this tab, user can browse the pictures already captured.


Specify whether to **delete** any of them. You can leave each picture with its default size or

- Specify if you want each picture to take a **full page**.
- Instead specify the **Height** and **Width** of each picture.



Option Tab

In this tab, you will specify the general options of the report, which will control its looks in the printout paper.



Specify to show or Hides,

- Header
- Footer
- Page Outline (the frame appears around the page)

In the Sheet Numbering Part, Specify the following:

- To include a **Prefix** (for instance the Word Page)
- The Starting Page number of the report.
- To include a **Suffix**, or not
- To **reverse** Page order, or not


In the table's Part, Specify:

- Whether the Table include a grid, or without grid
- Whether to start a new table in a new page, or not
- Specify the fonts for the for the column Header, and contents of the Tables.

Name & Logo Tab:-

In this Tab, you will specify the Name of the Company you represent, and its logo, which will appear in all of the Pages of the report.


In the white area, type the desired company Name.




In this Graphic Part, click File button, and select the logo file of the Company. Under the Position select the Placement of the logo, whether Left, Center or Right.

In the Text part, select the Font to be used in the Company Name. Then select the Placement of it, just you did in the logo Part.

Load/Save tab:- In this tab you will be able to save the report Contents. Click the Save As button, the following dialogue box will appear:



Type in the name of the report (no need for any extension) and click **OK**.



Next time you will find this file in the list, once you select it. It will be loaded.


Printing Reports

Print Preview Report

In order to see the final preview of the report without printing it. You can use this function, which will show all the contents as if they are on real paper. Use one of the following two ways:

- From the **Print Toolbar**, click the **Print Preview Report Icon**.
- From menus **File/Print Preview Report**.


You will get the following Screen:




- Use **Zoom In**, and **Zoom Out**, to see the default of the report, or the whole picture.
- You can see **One Page or Two Page** simultaneously.
- Use **Next Page**, or **Prev Page** to navigate through the pages of the Report.
- Use Print to Print out the report as is.

Print Report

In order to Print the report in pages, following are the methods:



 - From the **Print toolbar** click the **print icon**, or
From menus, select **File/Print/Report**.

Specify the following:

- The **Printer** you want to send to.
- The **Print Range**, All or certain page range.
- The number of Copies.

Export Report

We can Export the save report to:

- **Text File**
- **Ms Word File**

From menus select **File/Export Report**, and then Choose **Text File** or **Ms Word File**.

Print Preview Current View:

This option is used to preview the current structure that is displayed on the Screen.


From the **Print Toolbar** click the **Print Preview Current View** icon. 

Print Current View

This option is used to print the current structure that is displayed on the Screen.

From the Print toolbar click the Print Current View icon to print the current view. 

Export View

 -This option is used to export the current view that is displayed on the screen. From the Print toolbar click Export view with one of the famous graphics file format such as JPG, Tiff, Bmp, etc.,

Other Methods to Check the Results

Double-Clicking a Beam

When you double-click on the desired Beam, you will see the following dialogue box:

You can see in the above diagram, there in **Geometry, Property, Shear Bending & Deflection tabs.**

Geometry Tab:


In Geometry tab:

- You can check the Co-ordinates for the Beam you selected.
- You Can Change Beta Angle & Relations for the Beams.


Property Tab

In property tab,

- You can see **Moment of Inertia** about three directions & Area in three directions for the beam you selected.
- You can **Assign/Change** of the Beam.



- You Can see Material Properties Values that is assigned to the beam, and you can Assign Material from here itself.
- CH & L/s diagram.



Shear Bending Tab

In Shear Bending tab, first select the desired Load Case to View the Results for. Also choose Bending to Z direction or Shear in Y Direction or Bending in Y direction. Or Shear in Z direction.


You can see the following diagram:

Section Forces

Dist ft	Fy kN	Mz kip-in
6.666666666	-0.649	-2.836
7.5	-0.962	-1.025
8.333333333	-1.275	1.489
9.166666666	-1.587	4.706
10	-1.900	8.626

Table at the lower left portion of the dialogue box will show the values of FY, and MZ at 11 equal cross section of the Beam selected.

You will see the following Screen:




Deflection Tab:

If you select the Deflection tab, you will see the deflection diagram:

From the Selection Type part, Decide on the following:

- Desired Load Case so View the results for.
- The diagram type, you have, two choices: Global Defines (Using the Global X,Y and Z), and the Local Deflection (using the Local X,Y and Z)



Not For

ase